

## **Cell Projection to Extend Shaped-Beam-Litho for New Applications**

Matthias Slodowski, General Manager

# Cell Projection

## Early E-Beam Idea for New Applications Today

### IBM, 1979




Fig. 7. Character aperture shaping method.

Source: H. C. Pfeiffer, IEEE Trans. Electron. Devices ED-26, 663, 1979

### (Vistec), 1993





FIG. 1. Multiple beam-shaping diaphragm in the ZBA31/32. E-beam path.

Source: Elsner, Hahmann, J. Vac. Sci. Technol. B, Vol. 11, No. 6, Nov/Dec 1993



### eBeam Initiative, 2009



Drawing Courtesy Hitachi High-Technologies


Source: eBeam Initiative Website [ebeam.org](http://ebeam.org), Features Archive

### Applications, 2024



Source: Fraunhofer IOF, Jena / Germany

## Variable Shaped Beam (VSB)




electron beam

shaping deflection


positioning deflection

substrate


## Variable Shaped Beam Writing



# VSB and Cell Projection Seamlessly Integrated in the Same Hardware (switch electro-optically)



# VSB and Cell Projection Seamlessly Integrated in the Same Hardware (switch electro-optically)



## 2 Tool Types: Both Shaped Beam + Cell Projection



**SB250**

up to 200 mm wafer  
up to 7 inch mask





**SB3050**

up to 300 mm wafer  
up to 9 inch mask




# Cell Projection Hardware: Etched Mini-Reticle on Stencil-Chip on Piezo-Stage

**mini-reticle**  
etched into  
silicon membrane



multi **stencil chip**  
**more than 10.000 reticles**  
(depending on size)



fully automatic **reticle positioning**  
short range: by E-Beam deflection  
long range: by piezo stage positioning






## Data Preparation - General Remarks

- Complete toolbox available in Vistec's proprietary ePLACE data preparation system.
- Seamlessly integrated with Variable Shaped Beam including all corrections.
- **NEW: Exact Mathematical Function** instead of layout can be used to create exposure data to prevent vertice artifacts when fracturing a layout.
  
- 3 Ways to do Cell Projection Data Preparation ...


## Data Prep:

### Way 1: Create Layout out of existing Mini-Reticles

Layout and marking boxes




Layout is hierarchical and consists of Mini Reticles as basic cells.



ePLACE

Fractured Data (JES)




Cells are marked in yellow


# Data Prep:

## Way 2: Use Marking Boxes to support Cell Fracturing


Layout (slanted gratings)




Marking boxes



+



Fractured Data (JES)




Layout may be non-hierarchical.  
No pre-cuts to MR size are required.

Cells are marked in yellow  
VSB shots in green

# Data Prep:


## Way 3: Identify Cell Candidates in Arbitrary Layouts



**ePLACE**

offers tools to  
identify Mini Reticle  
candidates

# Data Prep: Continuous CD Tuning of Cells by Dose




CD-SEM measurement

# Data Prep: Curvilinear features

Angle-independent characteristic



High diffraction efficiency




High pattern fidelity

Low scattering



# Application Example 1: Effective Medium Blazed Grating



VSB, squares  
2.5 months





CP, dots  
1 day




Source: Fraunhofer IOF, Jena / Germany

# Application Example 2: High Quality Any Angle Gratings






# Application Example 3: Metamaterials: Small Structures + High Fidelity + Large Areas



**Plasmonic Nanostructures**



**Bow Tie & Spiral Arrays**




Source: IPHT Jena, Germany

## Shaped Beam + Cell Projection Fits New Applications

- Cell- or Character Projection has a long E-Beam history in different flavours.
- Vistec's solution is fully automated and seamlessly integrated with Variable Shaped Beam.
- Sophisticated and proven Hard- and Software is available, like more than 10.000+ mini reticles and appropriate Data Prep tools.
- Cell Projection increases throughput AS WELL AS pattern fidelity.
- Cell Projection fits especially optics and photonics mastering applications.

# Thank you for your attention !

and the whole Vistec team for its contributions.



## **Publisher**

Vistec Electron Beam GmbH  
Ilmstr. 4  
07743 Jena  
Germany

[www.vistec-semi.com](http://www.vistec-semi.com)

Tel.: +49 (0) 3641 7998 0

Fax: +49 (0) 3641 7998 222

The contents of this publication must not be reproduced in any form, or communicated to third party, without prior written permission of Vistec Electron Beam GmbH.

The use of trademarks, brand names etc. in this document does not entitle third parties to consider these names to be unprotected.

All reasonable steps have been taken to ensure that this publication is correct and complete. But should any user be in doubt about any detail, clarification may be sought from Vistec Electron Beam GmbH or their accredited representative. Vistec Electron Beam GmbH accepts no responsibility for any errors that may appear in this document.

Statements of this publication that refer to roadmaps, technology plans, and specifications are subject of change without notice.

Copyright © Vistec Electron Beam GmbH 2024. All rights reserved.